

User Manual of

Large Venue Motorized Projection Screen







Note: Please follow the instructions in this manual and keep it for future reference.

Installation

Parts Included

Our company reserves the right to the accessories contained in this manual, and we are subject to change without notice.

User Manual (1 pcs) Installation Tips Sticker (1 pcs)



(1 pcs)



User Manual (1 pcs)



Remote Control Receiver (1 pcs)



Controller (1 pcs)



Matters Needing Attention

Important Note

Please observe the following instructions, as incorrect installation and improper use may lead to mechanical failure or personal injury.

Installation Notes

- 1. Please handle with care to avoid damage.
- 2. Do not use in a wet environment.
- 3. Keep away from fire/heat.
- 4. Do not attempt to service or modify this unit without professional assistance.
- 5. Make sure the voltage is consistent. Incorrect connection of wires may result in leaks or fires.
- 6. To avoid damaging the screen, do not fold the screen or touch the screen directly with your hands, tools, or any other abrasive/sharp object.
- 7. When not in use, retract the screen to protect the optical surface.
- 8. Do not run the screen continuously as the motor has an anti-overheating function and will shut down.
- 9. Keep the screen horizontally.



When installing or repairing please use a professional.



Please do not take off the head-caps to avoid electric shock.

• We will not be responsible for damages done due to user error or false operation.

Please do not adjust the limit by yourself.


Cleaning

Do not use detergents or harsh chemicals to clean screen material. A soft cloth and mild soap can clean dust and dirt off the screen material. A cotton cloth can be used to gently wipe dust off of the screen.

Wall Mount Installation

According to LA, mark the 2 holes on the wall and drill 2 holes(40-60mm deep), please guarantee that 2 holes are on the same horizontal line.


Hang the screen onto the screws. Tighten the M5 screws, then installation completed.





Ceiling Mount Installation

Hang the projection screen on the hook, and check the safety of the hook, and take reasonable measures to ensure the projection screen will not fall off under any circumstances.




Usage

How to Use

Manual control and remote control are optional for motorized screens.

I.Manual Control:

Use the manual switch to control the screen up and down.





II.Built-in RF Remote Control / External RF Remote Control / IR Remote Control are optional for motorized screens.



- 1. Press the "Down" button and the projection surface will lower itself. When it is fully extended it will stop automatically.
- 2. Press the "Up" button and the projection surface will retract into its case. When it is fully retracted it will stop automatically.
- 3. Press the "Stop" button to stop manually at an intermediate position.

5





Format	Size	Viewing Area (W*H)	Installation Hole Distance	Housing Size (L*A*B)	Packaging Size
4:3	100"	2030*1520	2225	2225*95*150	2285*165*190
	120"	2435*1825	2635	2635*95*150	2695*165*190
	150"	3045*2285	3265	3265*95*150	3325*165*190
	180"	3655*2740	3905	3905*113*185	3990*175*240
	200"	4060*3045	4310	4310*113*185	4395*175*240
	250"	5080*3810	5510	5510*156*205	5630*230*350
	300"	6096*4572	6526	6526*156*205	6650*230*350
	350"	7112*5334	7542	7542*187*243	7670*260*400
	400"	8128*6096	8558	8558*226*284	8690*300*450

Format	Size	Viewing Area (W*H)	Installation Hole Distance	Housing Size (L*A*B)	Packaging Size
16:9	100"	2210*1245	2405	2405*95*150	2470*165*190
	120"	2655*1490	2855	2855*95*150	2920*165*190
	150"	3320*1865	3540	3540*95*150	3600*165*190
	180"	3985*2240	4235	4235*113*185	4320*175*240
	200"	4425*2490	4675	4675*113*185	4760*175*240
	250"	5535*3113	5965	5965*156*205	5630*230*350
	300"	6641*3736	7071	7071*156*205	6650*230*350
	350"	7748*4358	8178	8178*187*243	7670*260*400
	400"	8855*4981	9285	9285*226*284	8690*300*450