


SCREEN PRO


Synchronization Trigger

USER MANUAL



Synchronization Trigger

USER MANUAL



IMPORTANT Synchronizer supplied with the product:

Steps 1-4 (Synchronizer Pairing) have been preset at the factory. Under normal conditions, no re-pairing is required. After connecting your projector, proceed directly to Step 5 and complete Steps 5-7 (Current Learning). Synchronizer purchased separately: Please complete Steps 1-7 in sequence to complete both Synchronizer Pairing and Current Learning.

Synchronizer Pairing

- Step 1:** Connect the Synchronizer socket to the projector's power cable. Make sure both the projector and the screen are connected to power. Keep the projector in standby mode.
- Step 2:** Press and hold the screen's LEARN button until the screen automatically moves up and down once, then release the button. The screen is now in learning mode.
- Step 3:** Press and hold the LEARN button on the Synchronizer until the screen moves up and down once, then release the button.
- Step 4:** Pairing is complete. The Synchronizer is now paired with the screen.

Current Learning

- Step 5:** Turn on the projector and wait until the projected image appears normally.
- Step 6:** Using the adjusting stick, press and hold the LEARN button on the Synchronizer. Watch the indicator light. When it changes from green to red, continue holding the button. Release the button immediately when the red light turns off.
- Step 7:** Current learning is complete. The learned current setting has been saved



cn.